

Daylight Savings Time for 2007

As you may be aware daylight savings time is changing this year. It will now start three weeks earlier and end one week later than in previous years. You may be wondering how this new policy will affect your iMediaTouch system. The iMediaTouch products do not track time itself, it runs using the computer's system time. To ensure that your machine will change the time on the computer, make sure that you have upgraded the daylight savings time settings for your installation of Windows.

If you are running Windows XP or Vista this is handled by a downloadable patch. Run the Windows Update on your machine and under the Recommended Updates install the update for daylight savings time. It will be listed as a patch for Windows XP; you will have to read the descriptions to see what it is for. If you do not see it in the list, you may have already installed it.

If you are running Windows 2000 or earlier, Microsoft has decided not to support the new daylight savings time directly. They have issued a Tech Article located at:

<http://support.microsoft.com/kb/914387/en-us>

This will explain how to modify your registry to make the change for the new daylight savings time. If you are uncomfortable doing this process, you will have to set your machine to not adjust time for daylight savings and then change the time on that machine manually when the time comes.

You can read more about how to upgrade your system at:

<http://www.microsoft.com/dst2007>